




## 1. Exploded view and spare parts of the lift

The main spare parts of the lift are listed below. For the replacement of any other component, please contact METALU offices.


<b>4</b>	Seat	<b>68</b>	Control box support bracket
<b>5</b>	Seat base	<b>69</b>	Operating control unit (push-button panel)
<b>6</b>	Folding armrest	<b>70</b>	Battery charger
<b>8</b>	Folding footrest	<b>71</b>	Battery and control box cover
<b>8.1</b>	PVC base of the folding footrest	<b>72</b>	Electrical system microswitch
<b>35</b>	Seat support brackets	<b>73</b>	Front wheel
<b>43</b>	Covers for the front and rear supports	<b>74</b>	Rear wheel
<b>50</b>	Lift body	<b>75</b>	Front support knob
<b>59</b>	Actuator pin ring	<b>76</b>	Inner nut of the front support
<b>60</b>	Actuator	<b>76.1</b>	Inner support reinforcement plate
<b>61</b>	Actuator pin	<b>77</b>	Levelling element
<b>66</b>	Control box	<b>78</b>	Front and rear support leveller
<b>67</b>	Battery		



Exploded view and spare parts of the METALU S-400 lift.

## 10. Overall dimensions of the lift

The following image shows the dimensions of the METALU S-400 lift in relation to a standard pool profile, units in millimetres [mm].




\* The distance from the lift to the edge of the pool may vary between 50 mm and 120 mm; therefore, an average distance of 80 mm has been indicated. The dimensions marked with \*\* depend on this value.

\*\* These dimensions depend on the value indicated in the previous note (80 mm dimension).





In three-dimensional space, the limit positions of the lift are shown in the following image.



*Three-dimensional space dimensions of the S-400 lift.*

# MANUFACTURAS METÁLICAS LUISIANERAS, S.L.

## Battery-powered pool lift model METALU S-400

### Installation manual and certificates

**Address:** Polígono Industrial Los Motillos, C/ Madrid No. 11, units A, C, D, G, H. 41430.

**City:** La Luisiana (Sevilla) – España.

**Tax ID:** B – 41834508

**Main telephone:** +34 955 907 784

**Website:** [www.ascensoracuatico.com](http://www.ascensoracuatico.com)

**Email:** [info@ascensoracuatico.com](mailto:info@ascensoracuatico.com)

#### **Technical support contacts:**

- Telephone: +34 613 165 661
- Email: [soporte1@ascensoracuatico.com](mailto:soporte1@ascensoracuatico.com)



Otra documentación disponible:



Installation



Exploded view and  
troubleshooting



Additional  
accessories